

MKPULSE

PRO AUDIO · PARTY

VIBE 6

Quick-Start Guide

Portable Party Speaker with Dynamic RGB

ITEM #: MKPULSEVIBE6

LAUNCHING AUGUST 2026

Dual 6.5" Woofers · Dynamic RGB Lighting · Bluetooth + TWS Stereo Pairing · USB / microSD / AUX / FM

Get sound in minutes

Dual 6.5-inch woofers, dynamic RGB lighting, Bluetooth + TWS stereo pairing, and flexible playback through USB, microSD, AUX, and FM. Rechargeable and ready to bring the energy wherever the party goes.

Key features

- DUAL 6.5-INCH WOOFERS
- TWS STEREO PAIRING
- DYNAMIC RGB LIGHTING
- RECHARGEABLE BATTERY
- USB + MICROSD + AUX

Before you start

- Unpack on a clear surface and confirm every item from the carton list.
- Read the safety notes in the full handbook before first power-on.
- Plan speaker placement toward listeners, not into a hard back wall.

What's in the box

- MKPULSE VIBE 6 Party Speaker
- Charging Cable
- Remote Control
- User Manual

Note: speaker stands, microphones, and audio cables are sold separately.

Quick-start steps

1. Charge the VIBE 6 fully before first use.
2. Power on from the top panel.
3. Pair a phone over Bluetooth, or insert USB / microSD, or use AUX.
4. Set overall volume for the room — start moderate for dinner service.
5. Choose an RGB mode that matches the mood (restrained early, brighter later).
6. Optional: connect a wired mic for karaoke or hosting; enable TWS stereo pairing for a second unit.

Sound modes

Playback-first design — Bluetooth, USB, microSD, AUX, and FM cover most hospitality and party workflows.

Need the full detail?

Download the Product Handbook and Full Spec Sheet from the product page at themkpulse.com — free, no sign-up.

Support: info@themkpulse.com · Monday–Friday, 9am–5pm ET · MKPULSE — United States